



XS-82H/XS-83H/XS-84H Block Diagram Ver.3.0

Video Block



Audio Block



(*1) Phantom power and gain are enabled only for the R channels of analog input channels 1 and 2.

(*2) DOWN MIX: From the menu, set "OFF"/"STEREO > MONO"/"5.1ch > STEREO"/"5.1ch > MONO"

(*3) : XS-83H and XS-84H only

(*4) : XS-84H only