

V-40HD Owner's Manual Errata

Please make the following corrections to the Owner's Manual for the V-40HD.

Detailed Setup for Output 1/2 (p.47)

Incorrect

Scaling	Position H	-176 -- [0] -- +223	This sets the horizontal position.
---------	------------	---------------------	------------------------------------

Correct

Scaling	Position H	-175 -- [0] -- +175	This sets the horizontal position.
---------	------------	---------------------	------------------------------------

Detailed Setup for Composite (p.48)

Incorrect

Scaling	Zoom	50% -- [100%]	This sets the zoom ratio.
	Type	[Full], Letterbox, Crop, Dot by Dot, Manual	This selects the cropping format. For details of the values, see [Type] of [Scaling] in the Input menu (p. 46)
	Size H	-1000 -- [0] -- +1920	This sets the horizontal size.
	Size V	-540 -- [0] -- +1200	This sets the vertical size.
	Position H	-800 -- [0] -- +800	This sets the horizontal position.
	Position V	-400 -- [0] -- +400	This sets the vertical position.

Correct

Scaling	Zoom	50% -- [100%]	This sets the zoom ratio.
	Type	[Full], Letterbox, Crop, Manual	This selects the cropping format. For details of the values, see [Type] of [Scaling] in the Input menu (p. 46)
	Size H	-1000 -- [0] -- +1000	This sets the horizontal size.
	Size V	-540 -- [0] -- +540	This sets the vertical size.
	Position H	-200 -- [0] -- +200	This sets the horizontal position.
	Position V	-150 -- [0] -- +150	This sets the vertical position.

Added Item of the System Menu (p.50)

The following setting item is added to the system menu.

Field Sync Processing	OFF, [ON]	Turn this ON to synchronize the fields of interlace input and the OUTPUT 1.
-----------------------	-----------	---

Copyright © 2013 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

